



- | | |
|--------------------------|----|
| Power/Accessory/USB port | 1 |
| Full QWERTY keyboard | 2 |
| Navigation keys | 3 |
| Earpiece | 4 |
| Headphone jack | 5 |
| Camera key | 6 |
| Power/End key | 7 |
| Right Soft key | 8 |
| Clear key | 9 |
| OK/Navigation key | 10 |
| Volume keys | 11 |
| Talk/Send key | 12 |
| Left Soft key | 13 |
| Speakerphone key | 14 |

SAMSUNG mob!le

Please follow us at:



<http://facebook.com/SamsungMobile>



<http://twitter.com/SamsungMobileUS>
<http://twitter.com/SamsungService>



<http://youtube.com/SamsungMobileUSA>

"number one in brand loyalty nine years in a row"



Samsung mobile phones have been rated number one in brand loyalty by consumers nine years in a row, according to Brand Keys, a leading independent authority on brand loyalty.



Printed on FSC and SFI certified papers
with at least 10% post consumer waste.

selling points

- Music and Video Player
- Voice Recognition Software

selling features



QWERTY Keyboard



Text, Picture, and Video Messaging



2.0 Megapixel Camera with Camcorder

Samsung Telecommunications America
1301 E. Lookout Drive | Richardson, TX 75082 | 1.800.SAMSUNG

* Many of the services and features described herein are network dependent and may require additional subscription and/or usage charges. Not all features are available for purchase or use in all areas. Other conditions and restrictions apply. See carrier for more information. All usage and standby times are approximate. Battery performance depends on network configuration, signal strength, operating temperature, features selected, and voice, data, and other application usage patterns. Internet content/services designed for mobile devices.

** The Samsung Profile™ supports Bluetooth Profiles for wireless handsets, hands-free accessories, and object exchange. Both devices must be compatible with object exchange profile. Copyrighted material cannot be transferred.

©2010 Samsung Telecommunications America, LLC ("Samsung"). Samsung and Profile are trademarks of Samsung Electronics America, Inc. and/or its related entities. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated.

Printed in the U.S.A.

11/2010

SAMSUNG

Profile™
information guide



<https://training.samsungtelecom.com>
Carrier Code: **division**

Qualify the Customer

I want a phone that gives me plenty of options to stay in touch. I want to access social networking sites and have tons of messaging options. I also like to take and send lots of pictures so it needs to have a camera.

Secondary Features

- Text, Picture, and Video Messaging
- Threaded/Chat-style Messaging
- XT9® Predictive Text
- 2.0 Megapixel Camera with Camcorder
- Music and Video Player
- 3.5mm Headset Jack
- Voice Commands
- Internal Memory
 - Total Memory Available: 100MB
- External Memory
 - Up to a 16GB microSD™ Card**
- Stereo Bluetooth® Technology*

Technical Specifications

- CDMA 800MHz – PCS 1900MHz
- Dimensions: 2.11" x 4.59" x 0.59"
- Weight: 4.4 ounces
- Main Display: 2.4" QVGA TFT
- Standard Battery: 3.7 Volt Lithium Ion, 1,140mAh
- Talk Time: Up to 6 Hours
- Standby Time: Up to 300 Hours
- Hearing Aid Compatibility: M4/T3

Memory

- microSD™ Memory Card Slot
 - 16GB
- Internal Phone Book
 - Holds up to 1000 entries
- Last 90 Incoming, Outgoing and Missed Calls Log
- Speed Dial
 - Holds up to 999 entries
- Mass Storage (100MB)

Call Management & Features

- Voicemail*
- Caller ID*
- Call Forwarding*
- Call Waiting*
- Three-Way Calling*
- Speakerphone
- Soft Keys
- Shortcut Menu
- Internal Antenna
- Vibration Alert
- 72-Tone Polyphonic Ringtones
- Auto Key Lock
- Multilingual Text Display
 - (English, Spanish)
- Personal Tools
 - Calendar, Memo Pad, Alarm Clock, World Time, Calculator, Timer, Stopwatch, Converter, Tip Calculator

What's in the box?

- Samsung Profile™ Handset
- Standard Lithium Ion (Li-Ion) Battery
- Travel Adapter
- PC Data Cable
- User Manual

Accessories

Order at 1-800-SAMSUNG or www.samsung.com/accessories



Car Charger



microSD™ Card



Bluetooth® Headset

Tips

Automatically Saving Photos to an Optional microSD™ Memory Card

Users can set the phone to save pictures to the phone's memory or automatically save them to an optional microSD memory card. To set the phone to save to the memory card, touch the Camera key on the side of the phone, and then **Options > Tools icon > Memory > Card**.

Customizing the Navigation Key

The up, left and right Navigation keys can be customized.

To set these shortcuts:

1. Go to **Menu > Settings > Phone Settings > Shortcut Key**.
2. Select either **Up, Right** or **Left**.
3. Choose the shortcut to be associated with the key. Options include Bluetooth, Music Player, Messages, My Images, My Ringtones, Inbox, Tools, Calculator, Tip Calculator, Converter, Calendar, Alarm Clock, and Stop Watch.
4. Select **OK** to confirm the choice. Repeat for the right and left keys.

Why Samsung?

About Samsung Telecommunications America

Samsung Telecommunications America, LLC, a Dallas-based subsidiary of Samsung Electronics Co., Ltd., researches, develops and markets wireless handsets and telecommunications products throughout North America. For more information, please visit www.samsungwireless.com.

About Samsung Electronics Co., Ltd.

Samsung Electronics Co., Ltd. is a global leader in semiconductor, telecommunication, digital media and digital convergence technologies with 2009 consolidated sales of US \$116.8 billion. Employing approximately 188,000 people in 185 offices across 65 countries, the company consists of eight independently operated business units: Visual Display, Mobile Communications, Telecommunication Systems, Digital Appliances, IT Solutions, Digital Imaging, Semiconductor and LCD. Recognized as one of the fastest growing global brands, Samsung Electronics is a leading producer of digital TVs, memory chips, mobile phones and TFT-LCDs. For more information, please visit www.samsung.com

Demonstrate

How do I take a picture?

To Take a Picture:

1. In **Standby** mode, press the **Camera** key on the right side of the phone.
 2. Using the display as a viewfinder, point the camera lens at your subject.
 3. To take a photo, press the **Camera** key or **Center Select** key.
- To erase the photo, press the **Right** soft key.
 - To send the photo as part of a picture message, press the **Center Select** key.
 - To save the picture to memory, press the **Left** soft key.

How do I upload pictures to social sites?

To Upload Pictures to Social Sites:

1. In Standby mode, press **Messages**, then select **Social Networking**.
2. Choose **Facebook** or **MySpace**, then **Upload Picture**.
3. Select a picture, then press **OK**.
4. Enter a personalized upload email address and subject line, then press **Share**.



How do I access the music player?

To Access Your Music Player:

1. From the Home screen, select **Menu > Multimedia**.
2. Select **Music Player**, then press **Library** to access your music files.

How do I send a text message?

To Send a Text Message:

1. In **Standby** mode, press **Messages**, then select **Send Message > Text Message**.
2. Enter the phone number or email address of the recipient, then press the **Center Select** key.
3. Enter the text content of your message using the keyboard.
4. Press **Options** to complete the message text and set message send options.
5. Once you're finished entering the message and setting send options, press **Send**.

